

Title: Remote Controls: Comparison Chart

EC-1 (Yellow Dot)	Forward/Reverse
EC-2 (Red Dot) Focus button is black	Forward/Reverse Focus
EC-3 (White Dot) Focus button is grey	Forward/Reverse Focus Autofocus Override
EC-4 (Blue Dot) (Discontinued)	Forward/Reverse Focus Autofocus On/Off
EKTAGRAPHIC IR AV35	Forward/Reverse Focus Wireless
SP Remote w/Laser Printer	Forward/Reverse Focus Wireless
NOTE: Color dot is located on 5-pin plug at end of cord	

Remote Controls : Comparison Chart

AV615 (Discontinued)	Forward/Reverse RECORD slide advance pulses
AV625	Forward/Reverse REMOTE FOCUS (w/o autofocus) RECORD program pulse signals
AV632 (Discontinued)	REMOTE control for Tape Deck
AV612A (Discontinued)	Forward only (no Reverse)
AV622 (Discontinued)	Forward only (no Reverse) RESTART tape deck RECORD program pulse signals

NOTE: AV35 IR Remote also functions with AudioViewer Projectors (Receptacle accepts standard EBY 5-pin connector)

Remote Controls : Comparison Chart

S-AV (Discontinued)	Forward/ Reverse Remote Focus (w/o autofocus)
Early 550 (White) (Discontinued)	Forward/Reverse Remote Focus (rocker instead of Forward/Reverse buttons)
570, 580, 570-R, AV-580, late 550 (Red) (Discontinued)	Forward/Reverse Remote Focus (rocker Forward/Reverse)
EC Digital (Discontinued)	Forward/Reverse Random Access

RA-950, RA-960 (Discontinued)	Forward/Reverse Remote Focus Random Access
-------------------------------	--

Remote Controls : Comparison Chart

The following projectors do not use remotes (no 5-pin remote accessory outlet):

CAROUSEL Models

4000
600
600H